

THESYCON

Thesycon® Systemsoftware & Consulting GmbH








FUJITSU

Includes
EUROScope lite16FX
on-chip debugger



SK-16FX-144PMC-USB v1.1






Overview

■ Introduction

- [About the SK-16FX-144PMC-USB](#)
- [SK-16FX-144PMC-USB content](#)
- [Test it](#)
- [The hardware](#)
- [The software](#)



■ Try yourself


- [Software examples](#)
- [Program download](#)
- [New project](#)
- [EUROScope](#)
- [USB Library](#)

■ Optional tools

■ Contacts

■ Additional documents

- [Schematic 'SK-16FX-144PMC-USB'](#)
- [Data sheet MB96330 Series](#)
- [Hardware manual 16FX Family](#)
- [AppNote '16FX Hardware Setup'](#)
- [AppNote '16FX Getting Started'](#)
- [Customer Information 16FX](#)
- [EUROScope Reference Manual](#)
- [Customer Information EUROScope](#)
- [AppNote ,EUROScope'](#)
- [AppNote 'USB Mini-Host Mass Storage Class'](#)





About the SK-16FX-144PMC-USB

- The SK-16FX-144PMC-USB includes a low-cost evaluation board based on the Fujitsu 16FX microcontroller MB96330 Series

- The MB96330 Series includes the following features:




- Up to 544 KByte Flash Memory
- Up to 32 KByte RAM
- Up to 3 CAN controller 2.0B
- Up to 8 LIN-USART interfaces
- Two I²C interfaces
- USB-Host/-Function interface (MB96F33xU only)
- Timers (ICUs, OCUs, PPGs, others)
- ADC
- External interrupts
- Others



About the SK-16FX-144PMC-USB

■ Features of the SK-16FX-144PMC-USB board:


- Microcontroller MB96F338U
- 1x UART-Transceiver (SUB-D9 connector)
- 1x USB to serial converter (Type-B connector)
- 1x High-speed CAN-Transceiver (SUB-D9 connector)
- 1x USB-MiniHost (Type-A connector)
- 1x USB-Function (Type-B connector)
- 2x LED-Display (7-Segment)
- 2x 'User'-button
- 1x 'Reset'-button, 'Reset'-LED
- All 144 pins routed to pin-header
- On-board 5V and 3V voltage regulators, 'Power'-LED
- Power supply via USB (external power supply possible and recommended for providing USB-MiniHost functionality)





SK-16FX-144PMC-USB content

The SK-16FX-144PMC-USB contains

- SK-16FX-144PMC-USB evaluation board with MB96F338U
- USB cable
- Mini CD
 - Documentation, USB driver, Softune Workbench, Examples
 - „EUROScope lite 16FX“







Test it

- The microcontroller on the SK-16FX-144PMC-USB is already preprogrammed with a simple application.

- Connect the USB cable to your PC and the SK-16FX-144PMC-USB
- Install the USB driver from the CD
- Press the ‚Reset‘- Button
- The SK-16FX-144PMC-USB will automatically start counting
- The count direction can be changed by pressing the key buttons







Test it

Congratulations!


- You finished successfully the first test
- Now you will get more details about the SK-16FX-144PMC-USB
- You will learn more about
 - The on-board features
 - How to program the Flash
 - How to start your own application
 - On-chip debugging with EUROSope



The Hardware




Main features



7-Segment Display

P09_0 P09_5 P09_6 P09_1 P09_2 P09_4 P09_3 P09_7
P00_0 P00_5 P00_6 P00_1 P00_4 P00_3 P00_2 P00_7
SEG1: Port09 SEG2: Port00



The Hardware



The jumpers

JP3: DTR-Reset

1-2: DTR-Signal of the UART connector is connected to the MCU reset-pin.

2-3: DTR-Signal of the USB connector is connected to the MCU reset-pin.

Some terminal-programs, e.g. Fujitsu's Skwizard, allow to reset the evaluation board by using the DTR-Signal.

JP6: MD0 selection

Close this jumper to control the MD0 level by the RTS signal of the USB interface

S1: Mode selection

PROG: Program-mode

RUN: Run-mode

JP10: 5V / 3.3V

1-2: 5V supply is used

2-3: 3.3V supply is used

JP4: UART RX select


R-0: UART0=UART'A' / U-1: UART1=UART'B' (USB)


R-1: UART1=UART'A' / U-0: UART0=UART'B' (USB)

JP5: UART TX select



R-0: UART0=UART'A' / U-1: UART1=UART'B' (USB)

R-1: UART1=UART'A' / U-0: UART0=UART'B' (USB)





The Hardware



The jumpers (USB specific)

JP65: Data+ Line selection

- 1-2: Data+ line connected to USB-Function
2-3: Data+ line connected to USB-Host

JP66: Data- Line selection


- 1-2: Data- line connected to USB-Function
2-3: Data- line connected to USB-Host


JP64: Interrupt

- 1-2: USB Function VBUS-Interrupt
2-3: No VBUS-Interrupt for USB Function



JP67: USB Function HCONX

- Open: D+ is not pulled up
Closed: HCONX controls Pullup of D+






The Hardware





■ JP4, JP5 : UART selection

- UART0 and UART1 of the microcontroller can be used together with a typical RS232 SUB-D9 connector and a serial/USB converter
- The jumpers JP4 and JP5 routes the channel to the connector
- UART0 = USB-connector (X5), UART1 = Sub-D9 (X4) (default)
 - Setting of Jumper JP4 and JP5: U-0 / R-1



- UART0 = Sub-D9 (X4), UART1 = USB-connector (X5)
 - Setting of Jumper JP4 and JP5: U-1 / R-0







The Hardware

The microcontroller pins



Pin	Pin-name	On SK-16FX-144PMC-USB used by	Pin	Pin-name	On SK-16FX-144PMC-USB used by
1	VSS	GND	17	P13_5/PPG17	
2	C	'C' capacitors	18	P13_6/PPG18/IN8	
3	P11_7/IN5_R/A3		19	P13_7/PPG19/IN9	
4	P12_0/RX2_R/INT6_R/A4		20	P04_2/IN6/RX1/INT9_R/TTG6/TTG14	
5	P12_1/TX2_R/A5		21	P04_3/IN7/TX1/TTG7/TTG15	
6	P12_2/PPG0_R/A6		22	P04_4/SDA0/FRCK0/TIN0_R	
7	P12_3/PPG1_R/TIN4/A7		23	P04_5/SCL0/FRCK1/TIN2_R	
8	P12_4/PPG2_R/TOT4/A8		24	P04_6/SDA1	
9	P12_5/PPG3_R/TIN5/A9		25	P04_7/SCL1	
10	P12_6/PPG4_R/TOT5/A10		26	P05_0/AN8/ALARM0/SIN2/INT3_R1	
11	P12_7/PPG5_R/A11		27	P05_1/AN9/ALARM1/SOT2	
12	P13_0/PPG6_R/A12		28	P05_2/AN10/SCK2	
13	P13_1/PPG7_R/A13		29	P05_3/AN11/TIN3/WOT	
14	P13_2/TIN3_R/A14		30	P05_4/AN12/TOT3/INT2_R	USB
15	P13_3/TOT3_R/A15		31	P05_5/AN13/INT0_R/NMI_R	
16	P13_4/PPG16		32	P05_6/AN14/INT4_R	



The Hardware

The microcontroller pins (cont'd)



Pin	Pin-name	On SK-16FX-144PMC-USB used by	On SK-16FX-144PMC-USB used by
33	P05_7/AN15/INT5_R/OUT10_R		
34	P06_0/AN0/PPG0/CS0_R		
35	P06_1/AN1/PPG1/CS1_R		
36	VCC	MCUVCC	
37	VSS	GND	
38	P06_2/AN2/PPG2/CS2_R		
39	P06_3/AN3/PPG3/CS3_R		
40	P06_4/AN4/PPG4/CS4_R		
41	P06_5/AN5/PPG5/CS5_R		
42	P06_6/AN6/PPG6		
43	P06_7/AN7/PPG7		
44	AVCC5	MCUVCC	
45	AVRH5	MCUVCC	
46	AVRL5	GND	
47	AVSS5	GND	
48	P07_0/AN16/INT0/NMI	Key button 'INT0/NMI'	
49	P07_1/AN17/INT1		Key button 'INT1'
50	P07_2/AN18/INT2		
51	P07_3/AN19/INT3		
52	P07_4/AN20/INT4		
53	P07_5/AN21/INT5/SCK9_R		
54	P07_6/AN22/INT6/SOT9_R		
55	P07_7/AN23/INT7/SIN9_R		
56	P14_0/AN24		
57	P14_1/AN25		
58	P14_2/AN26		
59	P14_3/AN27		
60	P14_4/AN28		
61	P14_5/AN29		
62	P14_6/AN30		
63	P14_7/AN31		
64	P15_0/AN32		



The Hardware

■ The microcontroller pins (cont'd)



Pin	Pin-name	On SK-16FX-144PMC-USB used by	Pin	Pin-name	On SK-16FX-144PMC-USB used by
65	P15_1/AN33		81	X1A/(P04_1)	
66	P15_2/AN34		82	RSTX	Key button ,Reset'
67	P15_3/AN35		83	P08_0/TIN0/ADTG/INT12_R/CKOTX0	
68	HCONX	USB	84	P08_1/TOT0/INT13_R/CKOT0	
69	VCC3	VCC3V3	85	P08_2/SIN0/TIN2/INT14_R	UART0 (RXD)
70	UDP	USB Data+	86	P08_3/SOT0/TOT2	UART0 (TXD)
71	UDM	USB Data-	87	P08_4/SCK0/INT15_R	
72	VCC	MCUVCC	88	P08_5/SIN1/INT1_R	UART1 (RXD)
73	VSS	GND	89	P08_6/SOT1	UART1 (TXD)
74	MD0	Mode-Switch S1	90	P08_7/SCK1	
75	MD1	to VCC	91	P10_0/RX0/INT8_R	CAN0 (RX)
76	MD2	Mode-Switch S1	92	P10_1/TX0	CAN0 (TX)
77	X0	4 MHz Crystal	93	P10_2/SCK5	
78	X1	4 MHz Crystal	94	P10_3/SOT5	
79	VSS	GND	95	P10_4/SIN5/INT5_R1	
80	X0A/(P04_0)		96	P17_3/SIN9/OUT8	



The Hardware

■ The microcontroller pins (cont'd)



Pin	Pin-name	On SK-16FX-144PMC-USB used by	On SK-16FX-144PMC-USB used by
97	P17_4/SOT9/OUT9		
98	P17_6/OUT11/TTG18/INT3_R		
99	P09_0/PPG8/UBX	SEG1-A	
100	P09_1/PPG9/LBX	SEG1-B	
101	P09_2/PPG10/CS5	SEG1-C	
102	P09_3/PPG11/CS4/FRCK2_R	SEG1-D	
103	P09_4/OUT0/CS3	SEG1-E	
104	P09_5/OUT2/CS2	SEG1-F	
105	P09_6/OUT2/CS1	SEG1-G	
106	P09_7/OUT3/CS0	SEG1-DP	
107	P00_0/AD00/INT8/SCK7_R/TTG8_R	SEG2-A	
108	VCC	MCUVCC	
109	VSS	GND	
110	P00_1/AD01/INT9/SOT7_R/TTG9_R	SEG2-B	
111	P00_2/AD02/INT10/SIN7_R/TTG10_R	SEG2-C	
112	P00_3/AD03/INT11/SCK8_R/TTG11_R	SEG2-D	
113	P00_4/AD04/INT12/SOT8_R/PPG8_R	SEG2-E	
114	P00_5/AD05/INT13/SIN8_R/PPG9_R	SEG2-F	
115	P00_6/AD06/INT14/PPG10_R	SEG2-G	
116	P00_7/AD07/INT15/SCK8_R/PPG11_R	SEG2-DP	
117	P01_0/AD08/TIN1/CKOT1/TTG16_R		
118	P01_1/AD09/TOT1/CKOTX1/TTG17_R		
119	P01_2/AD10/SIN3/INT11_R/TTG18_R		
120	P01_3/AD11/SOT3/TTG19_R		
121	P01_4/AD12/SCK3/PPG16_R		
122	P01_5/AD13/SIN2_R/INT7_R/PPG17_R		
123	P01_6/AD14/SOT2_R/PPG18_R		
124	P01_7/AD15/SCK2_R/PPG19_R		
125	P02_0/A16/PPG12/CKOT1_R		
126	P02_1/A17/PPG13		
127	P02_2/A18/PPG14/CKOT0_R		
128	P02_3/A19/PPG15		



The Hardware

■ The microcontroller pins (cont'd)

Pin	Pin-name	On SK-16FX-144PMC-USB used by
129	P02_4/A20/IN0/TTG0/TTG8	
130	P02_5/A21/IN1/TTG1/TTG9/ADTG_R	
131	P02_6/A22/IN2/TTG2/TTG10	
132	P02_7/A23/IN3/TTG3/TTG11	
133	P03_0/ALE/IN4/TTG4/TTG12/TOT0_R	
134	P03_1/RDX/IN5/TTG5/TTG13/TOT2_R	
135	P03_2/WRLX/INT10_R/RX2	
136	P03_3/WRHX/TX2	
137	P03_4/HRQ/OUT4	
138	P03_5/HAKX/OUT5	
139	P03_6/RDY/OUT6	
140	P03_7/CLK/OUT7	
141	P11_4/OUT6_R/A0	
142	P11_4/OUT6_R/A0	
143	P11_6/IN4_R/A2	
144	VCC	MCUVCC



The Software

■ The SK-16FX-144PMC-USB CD includes the following software:

- Softune Workbench (development platform for Fujitsu microcontroller)
- MCU Flash programming tool and SKwizard terminal program
- USB driver for on-board USB-to-RS232 converter
- On-chip debugger “EUROScope lite 16FX”
- Software examples for the SK-16FX-144PMC-USB



■ Additionally you can order the latest „Fujitsu MICROS DVD“

- Includes documentation & software for all Fujitsu microcontrollers
- Please contact your local distributor

■ Please check our dedicated microcontroller website

<http://mcu.emea.fujitsu.com>

- for updates of the Flash programmer tool, utilities and examples
- for data sheets, hardware manuals, application notes, etc.




Installation of the USB-driver

■ Connect the SK-16FX-144PMC-USB to your PC's USB port



- Windows will ‘Found New Hardware: SK-16FX-144PMC-USB’ and the Hardware Wizard should start automatically
 - Note: The installation procedure may differ with different operating systems



- Do not connect to Windows Update to search for software
- Select ‘Install from a list or specific location (Advanced)’
- Within next windows select ‘Search for the best driver’ and browse on the CD to the folder ‘drive:\USB-Driver\Win2000_WinXP’




Installation of the USB-driver





- ‘Continue anyway’ although the Windows Logo test may not be passed
- Windows completes the installation by copying some files
- ‘Finish’ will close the window







Installation of the USB-driver



- Again Windows will 'Found New Hardware: USB Serial Port' and the Hardware Wizard should start automatically
 - Note: The installation procedure may differ with different operating systems



- Do not connect to Windows Update to search for software
- Select 'Install from a list or specific location (Advanced)'
- Within next windows select 'Search for the best driver' and browse on the CD to the folder 'drive:\USB-Driver\Win2000_WinXP'




Installation of the USB-driver



- ‘Continue anyway’ although the Windows Logo test may not be passed
- Windows completes the installation by copying some files






Installation of the USB-driver

■ Start the Device Manager of the Windows Control Panel

- START -> Settings -> Control Panel
- Control Panel -> System -> Hardware -> Device Manager




■ Check 'Ports' for the assigned virtual COM-port number

- FUJITSU Microcontroller board (e.g.: COM4)



■ Ready!

- The SK-16FX-144PMC-USB can be powered via USB (default, JP11)
- Depending on JP4 and JP5 one UART is connected to USB




The Development Software

■ Softune Workbench

- Free of charge (only registration is required)
- Windows based development platform for all 16-bit microcontrollers
- Includes: Editor, C-compiler, assembler, linker, core simulator
- Supports optional hardware emulator
- Requires 'administration' or 'power user' rights on the PC
- Registration^{*1}
 - https://mcu.emea.fujitsu.com/cusreg/htm/cusreg_form.htm
 - Receive your password for Softune Workbench by email
 - Receive your license file for EUROSope by email
- Start installation
 - Enter password and choose destination folder (e.g. c:\Softune16)


^{*1} Note: If you want to use EUROSope please install and run it first and note down the Host ID (MAC address) of your PC system. This ID is needed to be filled out in the registration form to obtain a license key.




The FLASH Programmer

MCU Flash programmer

- Free of charge, no registration required
- Windows based programming tool for all 16-bit Fujitsu microcontroller
- Uses PC serial port COMx (incl. virtual COM port: USB-to-RS232)
- Start installation





Tools and Software Examples

■ SKwizard

- Free of charge terminal program
- [Start installation](#)

■ Following examples are provided with SK-16FX-144PMC-USB:



- [sk16fx144pmc_adc_dvm](#)
 - Digital Voltage Meter based on the A/D-converter
- [sk16fx144pmc_can_uart_terminal](#)
 - Simple CAN example controlled by UART1
- [sk16fx144pmc_counter](#)
 - Counts from 0 to 99 on the 7-segment Display
- [sk16fx144pmc_template](#)
 - ,Empty' project as base for user applications
- [sk16fx144pmc_uart](#)
 - UART example using UART1
- [sk16fx144pmc_usb_host](#)
 - USB Host example
- [96330-usb_bootloader](#)
 - USB Host Bootloader example

Note:

Do not connect other than [EUROScope](#) to UART0 ([default: X5/USB](#)).


All examples (except USB-Host examples) are prepared to be used with EUROSope and UART0 is reserved for this debugger.







Program Download

- Start the Fujitsu MCU Flash programmer
- Select the target microcontroller (MB96F338R/U/Y)
- Select the crystal frequency (4 MHz)
- Choose the software example from the example ‘ABS’-folder
(e.g. D:\Examples\sk16fx144pmc_counter-v10\ABS\sk16fx144pmc_counter.mhx)





Program Download



■ Connect to the PC

- RS232 or USB can be used
- Select COM port ('Set Environment')


■ Set jumper S1 to position ,Prog'

■ Press ,Reset'


■ Start ,Full operation'


S1: Mode selection

Prog: Set switch to position ,Prog' in order to select the program-mode





Keybutton ,RESET'







Program Download




- Close the MCU Flash programmer
- Set jumper S1 to position ,RUN‘
- Press ,Reset‘

S1: Mode selection


Run: Set switch to position ,RUN‘
in order to select the RUN-mode






New Project

- In order to start a new user project use the template project
 - This project includes the startup code, header files, and vector table
- Copy the folder ‘Template’ within the example folder
 - Rename ‘Copy of sk16fx144pmc_template-v10’ to ‘my_application’





New Project

■ Enter 'my_application'-folder

- Rename 'sk16fx144pmc_template.prj' into 'my_application.prj'
- Rename 'sk16fx144pmc_template.wsp' into 'my_application.wsp'

■ Edit 'my_application.prj'

- rename 'sk16fx144pmc_template' -> 'my_application'

■ Edit 'my_application.wsp'


- rename 'sk16fx144pmc_template' -> 'my_application'

sk16fx144pmc_template.prj - Notepad

```
File Edit Format View Help  
LST=LST\  
OPT=OPT\  
  
[MEMBER-Debug]  
F0=5  
F1=0 m 1 ABS\sk16fx144pmc_template.abs  
F2=0 a 1 Src\Start.asm  
F3=1 c 1 Src\Main.c  
F3-1=- src\mb96338us.h  
F4=1 c 1 Src\vectors.c  
F4-1=- src\mb96338us.h  
F5=0 a 1 Src\mb96338us.asm
```


sk16fx144pmc_template.wsp - Notepad


```
File Edit Format View Help  
[CPUType]  
CpuUserise=907  
  
[PrjFile]  
Count=1  
FILE-0=sk16fx144pmc_template.prj  
ActivePrj=sk16fx144pmc_template.prj  
  
[SubPrj]=sk16fx144pmc_template.prj  
Count=0  
  
[Debstate]  
Autosave=1  
Exec=0  
AutoLoad=1
```



New Project

■ Start Softune Workbench and open your project





New Project



■ Write your application code

- Start.asm : Startup code
- Vectors.c : Vector table
- Main.c : Your application

```
#include "mb96300.h"

/*
 * Dummy main() function. It calls the initialization of the interrupt
 * table, sets the interrupt level mask (ILM) to allow all interrupts
 * (ILM=7), and enables interrupts globally.
 */


void main(void)
{
    InitIrqLevels();
    __set_il(7);           /* allow all levels */
    __EI();                /* globally enable interrupts */

    // initialize I/O-ports


    PDR00 = 0xFF;
    DDR00 = 0xFF;          // Set Port00 as output (7Segment Display)

    PDR07 = 0x00;
    DDR07 = 0xFC;          // P07_0: SW2(INT0)  P07_1: SW3(INT1)
    PIER07 = 0x03;

    PDR08 = 0x00;
```





New Project




Compile and build your project

- Generates the MHX-file, which can be programmed to the Flash







New Project



Congratulations!

You have finished your first project

- Please see our application note
[‘16FX Getting Started’](#)
for a more detailed introduction.




EUROScope lite 16FX

„EUROScope lite 16FX“ source-level debugger

- On-chip debugging for 16FX microcontroller
- No kernel linkage / upload required
- Breakpoints
- Single step debugging (step, step-in, step-out)
- Windows for memory, watch, mixed source code, register
- Plug-ins available for operating systems etc.







EUROScope lite 16FX Installation





■ Installation of „EUROScope lite 16FX“

- Start „EUROScope lite 16FX“ for installation
- Choose „Fujitsu F16LX / F16FX“ from list






EUROScope lite 16FX Installation




■ License for „EUROScope lite 16FX“



- Run EUROScope.exe
 - Copy Host ID (MAC address) of your PC system
 - Request Lite key at
https://mcu.emea.fujitsu.com/cusreg/htm/cusreg_form.htm
 - Receive license key file from company EUROS by email
 - Copy license key file (*euros-license.key*) to your local installation path

Host ID of
your PC
system





EUROScope lite 16FX Project preparation



■ All examples within this package are already prepared for the use with EUROSope

- Default connection: UART0 routed to X5/USB.


■ In case of new projects or project modifications

- Use Softune Workbench
- Setup the Background Debugging area
 - See *Start.asm* (v1.34), chapter 4.18 (Enable Background Debugging Mode) and chapter 5.9 (Debug Address Specification)
 - See always the latest 'sk16fx144pmc_template' example
- Build your application project with Softune Workbench
 - Loadmodule (*.abs) format is required for debugging




■ Download your project (*.mhx) to the board

- Use the Fujitsu MCU Flash programmer




EUROScope lite 16FX Configuration






Start EUROSope

Ensure the following settings

- Select Target Connection ①
 - Choose Fujitsu 16FXBootROM (RS232)
- Configure Target Connection ②
 - Choose the COM port of the [Debug-UART](#) (Default: UART0 routed to X5/USB)
 - Choose the baudrate used in the Debug Address Specification of the *Start.asm* file (Default: 115200)
 - Choose „asynchronous communication“ and „Int/Ext vector mode“





EUROScope lite 16FX

Load ABS file




Load the *abs* file of your project

- File / Open Application ...

E.g.: <drive>:\Examples\sk16fx144pmc_counter-v10\ABS\sk16fx144pmc_counter.abs

Projects may be compiled on another PC or folder structure than the debug PC


- Adjust the source path ①
 - Click New (Insert) ②
 - Browse to source folder ③





EUROScope lite 16FX

Connect to device



- Start communication (*Communication -> Open*)
- Press reset button
- Communication is established, if code in the assembly and source code window is visible

Assembly window

Source code window

```
EUROScope - [c:\work\mb96340\io_euros\src\main.c]
File Target Communication Tools Preferences View Window ? 
Code: 0x00E00E (main: main + 0x30)
1 /* THIS SAMPLE CODE IS PROVIDED AS IS AND IS SUBJECT TO ALTERATIONS. FUJITSU */
2 /* MICROELECTRONICS ACCEPTS NO RESPONSIBILITY OR LIABILITY FOR ANY ERRORS OR */
3 /* ELIGIBILITY FOR ANY PURPOSES. */
4 /* (C) Fujitsu Microelectronics Europe GmbH */
5 /*
6 * MAIN.C
7 * - description
8 * - See README.TXT for project description and disclaimer.
9 */
10 /*
11 *-----*
12 *
13 #include "mb96346rw.h"
14
15 volatile unsigned long cnt;
16
17 void main(void)
18 {
19     InitIrqLevels();
20     __set_il(7);           /* allow all levels           */
21     __EI();               /* globally enable interrupts */
22
23     PDR00 = 0x00;          /* switch off all leds        */
24     DDR00 = 0xFF;          /* set parallel port direction register : output */
25
26     while(1)
27     {
28         for(cnt = 0; cnt < 80000; cnt++)      /* wait */
29             PDR00++;
30     }
31 }
```

Register unknown register

R10=012A0000	R11=00000044	R12=00000000				
RW0=0000	RW1=012A	RW2=0044	RW3=0000			
RW4=0000	RW5=0000	RW6=0000	RW7=00FE			
R0=00	R1=00	R2=00	R3=00	R4=00	R5=00	
R6=FE	R7=00					
A=00013880	AH=0001	AL=3880				
PC=FE00E9	SSP=004540	USP=004546				
DPR=42	DTB=00	ADB=00				
PS=E0E4	ILM=7	RP=00	CCR=E4			
I=1	S=1	T=0	N=0	Z=1	V=0	C=0

Memory: 0x2 (MB96346RW: _pdr02)

000000	FF00	FFFF	FFFF	FFFF
000001	FFFF	FFFF	FFFF	FFFF
000010	0000	0000	0000	0000
000018	0000	0000	0000	0000
000020	00E3	4000	0015	4000
000028	600C	0000	0000	600C

Breakpoints

Breakpoint	Module	Address	Flags
main + 0x30	main	FE00E9	XH

EUROSObjects


EUROS not found

EUROS OS trace
No Trace Buffer found

Timeline Event List Event Classes Entities Coverage


Stopped by Breakpoint

Ln 31, Col 2 FFMC16LX STOPPED CONNECTED




EUROScope lite 16FX

Start Debugging



- Initialize target and run until main function




- Use menu bar for debugging

Set Start address

Run

Stop


Set breakpoint




Single Step
(over
functions)

Step in

Step out



EUROScope lite 16FX Breakpoints



■ Set a breakpoint


- Double-click to desired line
 - ,C‘ code source: selectable lines are marked by small dot in front
 - ,Assembly‘ window: all lines with an instruction can hold a breakpoint
 - Some lines in source code window are grouped. When setting a breakpoint all grouped lines getting the red filled circle, but this is treated as only one breakpoint

■ Activate/deactivate breakpoints



- Single-click to breakpoint

■ Delete breakpoint

- Double-click to breakpoint until red filled (or white filled) circel disappears



EUROScope lite 16FX Breakpoints



Short explanation of EUROScope source code window

Yellow arrow shows actual programm counter


Point indicates breakable source code line

```
131 <span style="color: yellow;">131
```

Active breakpoint

Deactivated breakpoint

Lines between points indicate a group of breakable lines



EUROScope lite 16FX Processor Status



- Processor window provides most important registers
- All processor flags are shown individually
- All values can be changed
- Window is updated on any stop or break of the application
- Changes in values are displayed in red due to prior update

```
Register: unknown register
RL0=01CC0000  RL1=00F80004  RL2=00020000
RL3=00F80000

RW0=0000  RW1=01CC  RW2=0004  RW3=00F8
RW4=0000  RW5=0002  RW6=0000  RW7=00F8

R0=00  R1=00  R2=02  R3=00  R4=00  R5=00
R6=F8  R7=00


A=00660066  AH=0066  AL=0066

PC=F80169  SSP=00253E  USP=002544

DPR=22  DTB=00  ADB=00


PS=EOE5  ILM=7  RP=00  CCR=E5

I=1  S=1  T=0  N=0  Z=1  V=0  C=1  TBR=0000
```




EUROScope lite 16FX

Variable Window




Variables						
Variable	Value	Type	Storage	Module	Address	Size
cnt1	22 ''	char	0x2246	main	0x2246	1 byte
cnt2	9 ''	char	0x2245	main	0x2245	1 byte
cntdir	0 ''	char	0x2244	main	0x2244	1 byte
delay	40144	unsigned long	0x2240	main	0x2240	4 byte






EUROScope lite 16FX Memory View




- Memory view is updated on every stop or break
- Value change is displayed in red due to prior update
- Memory content can be changed
- Memory can be filled with a user byte and size

Memory: 0x2 (MB96346RW: __pdr02)							
000000	FF00	FFFF	FFFF	FFFF
000008	FFFF	00FF	0000	0000
000010	0000	0000	0000	0000
000018	0000	0000	0000	0000
000020	008C	4080	00C0	4080	0.	0.



EUROScope lite 16FX

Changing/Adding Source Window






New source module window

- Go in window tab area and right-button click
- Choose „New Source window“



Change source window

- Get menu by right-mouse-button-click in the source window
- Choose „Show Module...“
- Browse to Module File






EUROScope lite 16FX Flash Programming





■ Flash programming is available via the Flash button:


- BDM configuration can be set before programming
- Chip erase is supported
- Flash programming is supported
- User has to press reset button after Flash programming
- Fujitsu Flash programming kernels are reused



EUROScope lite 16FX BDM Configuration




- Background debugging mode configuration
- Flash security unlock



Flash security unlock keys


BDM Activation

[√] Use EUROScope configuration
[] Use MHX file configuration



EUROScope lite 16FX


Flash Programming Dialog



Chip erase and Flash programming


- Click on 'Done' and reset board after programming

Chip erase
(,all sectors' must be checked)





Browse to MHX file

Flash programming



EUROScope lite 16FX

Prospect



- All SK-16FX-144PMC-USB examples* are configured as follows:

- UART0 for debugging
- UART1 may be used by the application
- Asynchronous communication
- 115200 bit/s
- Autorun after reset
- No breakpoint predefinition



- For more details of „EUROScope lite 16FX“
please refer to application note

- [mcu-an-300235-e-16fx_using_EUROScope](#)

and take care of the following customer information

- [Customer Information EUROScope](#)

(*) except USB Host examples




■ The MB96F338U microcontroller offers USB-Host/-Function that is supported by SK-16FX-144PMC-USB

- USB-MiniHost (Type-A connector)
- USB-Function (Type-B connector)


■ The company **Thesycon** provides two free-of-charge libraries implemented in C and provided as source code




- FUFA - Fujitsu USB Firmware API for USB function
- FUMA - Fujitsu USB Minihost API for USB minihost

<http://www.thesycon.de>




**Host
Jumper
Setting**







■ Access to a Memory Stick is shown by a demo example

- [sk16fx144pmc_usb_host](#)
- incl. FUMA library
- incl. FAT16 file system from Elm Chan
http://elm-chan.org/fsw/ff/00index_e.html
- Set USB-Host [jumpers](#)
- [Download](#) the example
sk16fx144pmc_usb_host.mhx
- Connect [UART0](#) to your PC
- Start your terminal program with 115.200 Baud, 8N1
e.g. [SKwizard](#)
- Connect your Memory Stick
- Press Reset
- For details please see the
readme.txt of the example
or the [Application note](#)





USB (VID / PID)



Do you need an USB VID / PID ?





■ If you need an USB VID / PID for development and prototyping then please contact FUJITSU in order to get your sublicense:

- Contact: micro_info@fme.fujitsu.com
- Subject: “USB VID / PID sublicense”

■ In order to get your proper VID /PID please contact **USB.org**

- <http://www.usb.org>
- <http://www.usb.org/developers/vendor/>






Further Steps

■ In order to learn more about Fujitsu's microcontrollers

- Visit our microcontroller website
 - <http://mcu.emea.fujitsu.com>
 - http://mcu.emea.fujitsu.com/mcu_product/detail/MB96F338UWAPMC.htm
- See our application notes
 - http://mcu.emea.fujitsu.com/mcu_product/mcu_all_appnotes.htm
- See our software examples
 - http://mcu.emea.fujitsu.com/mcu_product/mcu_all_software.htm

■ Contact your local distributor ...

- for individual support
- to register for our monthly 16FX seminar
- to order the latest 'Fujitsu Micros DVD' containing all information regarding Fujitsu's 8-bit, 16-bit, and 32-bit microcontrollers



Optional Tools

■ High-end evaluation board

- SK-96330-144PMC-GDC
- SK-96330-144PMC

■ Hardware emulator


- MB2198-01 + MB2198-500
- Emulation chip MB96V300B
- Probe header MB2198-506-E for LQFP package M08
 - Socket NQPACK144SD-ND, HQPACK144SD

■ Programmer

- Conitec GALEP-4, GALEP-5

■ Operating systems


- ProOSEK®, EUROS, RTA-OSEK, embOS, osCAN, FreeRTOS



Evaluation Board

■ SK-96330-144PMC-GDC




- Evaluation board for MB96330 Series
- Access to all on-chip peripherals
- Ext. Bus Interface (e.g. for Fujitsu Graphic Controller Boards)
- USB-Host/-Function connectors
- 2x UART/LIN
- 2x CAN
- 8x 'User'-LEDs
- 5x 'User'-Buttons
- Connector for LC-Display
- 8 MB Flash
- 2 MB SRAM



■ SK-96330-144PMC

- without external memory
- without GDC interface






Hardware Emulator

■ In-Circuit emulator for F2MC-16FX

- Main unit (MB2198-01), Adapter (MB2198-500), V-Chip (MB96V300B)
- USB, LAN, and RS232 communication interface
- Connected to target system via standard Fujitsu probe cable
- High speed operating frequency
- 2052 code / 4 data event breakpoints
- Sequential breakpoints (4 conditions / 3 levels)
- Trace function






Hardware Emulator




■ Emulation chip MB96V300B

- Superset supports all features of 16FX




■ Probe header


- MB2198-506-E for LQFP package M08



■ Socket for LQFP package M08

- NQPACK144SD-ND, HQPACK144SD






Programmer



■ GALEP-4 / GALEP-5

- Supports parallel programming
- Supports serial synchronous and asynchronous programming
- Optional programming cable for serial synchronous programming
- Allows programming in volume production
- www.conitec.com





Operating Systems

■ ProOSEK®

- Real-time operating system, OSEK/VDX
- www.elektrobit.com

■ EUROS

- RTOS including TCP/IP, IrDA, IDE, CAN-Bus, CANopen, Profibus, etc.
- www.euros-embedded.com

■ RTA-OSEK

- Realogy Real-Time Architect (RTA) ,OSEK, incl. timing analysis tool
- www.etasgroup.com

■ embOS



- Small memory footprint for single-chip applications incl. PC viewer
- www.segger.com

■ osCAN (OSEK/VDX)

- osCAN (OSEK/VDX) and further networking software CAN, LIN, FlexRay, etc.
- www.vector-informatik.de

■ FreeRTOS

- Free and open source mini Real Time Scheduler
- www.FreeRTOS.org



Contacts - Distribution

■ European distributors

- ATeG - Anatec AG
- ATeG - Anatronic S.A.
- ATeG - Ineltek GmbH
- EBV Elektronik GmbH
- Glyn GmbH & Co. KG
- Malpassi srl
- Melchioni Electronica SpA
- PN Electronics
- Rutronik
- Sagitrón

www.anatec.ch

www.anatronic.com

www.ineltek.com

www.ebv.com

www.glyn.de , www.glyn.ch



www.malpassi.it

www.melchioni.it

www.pne.fr

www.rutronik.com

www.sagatron.es/english.htm



Fujitsu Microelectronics Europe

■ Germany (Headquarters)

- Pittlerstrasse 47, D-63225 Langen
- Tel: (0 61 03) 69 00, Fax: (0 61 03) 69 01 22

■ France

- 2-12 Chemin des Femmes, F-91300 Massy
- Tel: (01) 64 47 97 07, Fax: (01) 64 47 97 01

■ Italy

- Palazzo Pitagora – Milano 3 City, Via Ludovico il Moro 4B, I-20080 Basiglio, Milano
- Tel: (02) 90 45 02 1, Fax: (02) 90 75 00 87


■ United Kingdom

- Network House, Norreys Drive, Maidenhead, Berkshire SL6 4FJ
- Tel: (01628) 50 46 00, Fax: (01628) 50 46 66

■ World Wide Web

- <http://emea.fujitsu.com/microelectronics>
- <http://mcu.emea.fujitsu.com>
- Contact: micro_info@fme.fujitsu.com





Recycling




■ Gültig für EU-Länder:

- Gemäß der Europäischen WEEE-Richtlinie und deren Umsetzung in landesspezifische Gesetze nehmen wir dieses Gerät wieder zurück.
- Zur Entsorgung schicken Sie das Gerät bitte an die folgende Adresse:

■ Valid for European Union Countries:

- According to the European WEEE-Directive and its implementation into national laws we take this device back.
- For disposal please send the device to the following address:

Fujitsu Microelectronics Europe GmbH
Warehouse/Disposal
Monzastraße 4a
D-63225 Langen



CD Contents

■ Software

- [Softune Workbench](#)
- [EUROScope lite 16FX](#)
- [MCU Flash programmer](#)
- [SKwizard](#)
- [Thesycon USB driver](#)

■ Documents

- [Schematic 'SK-16FX-144PMC-USB'](#)
- [Data sheet MB96330 Series](#)
- [Hardware manual 16FX Family](#)
- [AppNote '16FX Hardware Setup'](#)
- [AppNote '16FX Getting Started'](#)
- [Customer Information 16FX](#)
- [EUROScope Reference Manual](#)
- [Customer Information EUROScope](#)
- [AppNote ,EUROScope'](#)
- [AppNote 'USB Mini-Host Mass Storage Class'](#)

■ Software Examples

- [sk16fx144pmc_adc_dvm](#)
- [sk16fx144pmc_can_uart_terminal](#)
- [sk16fx144pmc_counter](#)
- [sk16fx144pmc_template](#)
- [sk16fx144pmc_uart](#)
- [sk16fx144pmc_usb_host](#)
- [96330-usb_bootloader](#)