## MEDICAL 200 W AC/DC - Single Output



### **Features**

- 160 W convection cooled
- -20 to 50 deg C full load operation
- 3" x 5" x 1.5" (76.2 x 127 x 38.1 mm)
- No minimum load required
- 2 X MOPP Isolation
- 12 V fan & 5 V standby
- Inhibit function
- Conducted EMI EN 55022-B, FCC Part 15 Level B
- Safety approval to UL/CSA/EN/IEC60950-1
- RoHS Compliant

Applications: Diagnostic, Drug Pump, Dialysis, Home Health Care, Monitoring

### **ELECTRICAL SPECIFICATIONS**

#### **INPUT:**

Input voltage range:	Universal Input	90 - 264 Vac
		120 – 390 Vdc
Input frequency range:		47-63 Hz
Input surge current:	230 Vac (cold start)	65 A max.
Safety ground leakage current:	230 Vac	300 μA max
Input current:	120 Vac @ 200 W	2.4 A
	230 Vac @ 200 W	1.2 A

#### **OUTPUT:**

Voltage Adjustment	V1	± 3%
Transient Response	Main output 50 to 100% load change	< 10%, recovery time < 5 mS
Over Voltage Protection	V1	110 to 150% rated max
Over Current Protection	Rated output current	110% Typical
Short Circuit Protection	Automatic recovery	

# MEDICAL 200 W AC/DC - Single Output

#### ORDERING INFORMATION:

Product Family	Vout (Vdc)	Max Load Convection (1)	Max Load 300 LFM (1)	Minimum Load (A)	Ripple & Noise (3)	Connector	Total Regulation
MBC201-1005G	5.0	26.0 A	26 A	0	1%	JST	± 2.5%
MBC201-1005G-2	5.0	26.0 A	26 A	0	1%	JST	± 2.5%
MBC201-1T05G	5.0	26.0 A	35 A	0	1%	Screw Terminal	± 2.5%
MBC201-1T05G-2	5.0	26.0 A	35 A	0	1%	Screw Terminal	± 2.5%
MBC201-1012G	12	13.33 A	16.67 A	0	1%	JST	± 2.5%
MBC201-1012G-2	12	13.33 A	16.67 A	0	1%	JST	± 2.5%
MBC201-1T12G	12	13.33 A	16.67 A	0	1%	Screw Terminal	± 2.5%
MBC201-1T12G-2	12	13.33 A	16.67 A	0	1%	Screw Terminal	± 2.5%
MBC201-1015G	15	10.66 A	13.33 A	0	1%	JST	± 2.5%
MBC201-1015G-2	15	10.66 A	13.33 A	0	1%	JST	± 2.5%
MBC201-1T15G	15	10.66 A	13.33 A	0	1%	Screw Terminal	± 2.5%
MBC201-1T15G-2	15	10.66 A	13.33 A	0	1%	Screw Terminal	± 2.5%
MBC201-1024G	24	6.66 A	8.33 A	0	1%	JST	± 2.5%
MBC201-1024G-2	24	6.66 A	8.33 A	0	1%	JST	± 2.5%
MBC201-1T24G	24	6.66 A	8.33 A	0	1%	Screw Terminal	± 2.5%
MBC201-1T24G-2	24	6.66 A	8.33 A	0	1%	Screw Terminal	± 2.5%
MBC201-1030G	30	5.33 A	6.66 A	0	1%	JST	± 2.5%
MBC201-1030G-2	30	5.33 A	6.66 A	0	1%	JST	± 2.5%
MBC201-1T30G	30	5.33 A	6.66 A	0	1%	Screw Terminal	± 2.5%
MBC201-1T30G-2	30	5.33 A	6.66 A	0	1%	Screw Terminal	± 2.5%
MBC201-1048G	48	3.33 A	4.17 A	0	1%	JST	± 2.5%
MBC201-1048G-2	48	3.33 A	4.17 A	0	1%	JST	± 2.5%
MBC201-1T48G	48	3.33 A	4.17 A	0	1%	Screw Terminal	± 2.5%
MBC201-1T48G-2	48	3.33 A	4.17 A	0	1%	Screw Terminal	± 2.5%
Vfan (all models)	12	0.5 A	0.5 A	0			± 20%
V s/b (all models)	5	1.0 A	1.0 A	0			± 5%

#### Notes:

- 1. Combined power from main output Vfan and Vs/b should not exceed total power rating.
- 2. Fan output tolerance is ± 20%. When V1 full load, Vfan needs 20 mA load to be within regulation specification. Peak current for fan output is 1 A.
- 3. Ripple is 2% upt to 20 load and less than 1% above 20% load. Output nose measurement is made with a 20 MHz bandwidth using a 6" twisted pair, terminated with a 10 uF tantalum capacitor in parallel with a 0.1 uF ceramic capacitor.
- 4. For the -2 suffix (class 2 products) of MBC201-10XX-2, it indicates that the class 2 products have no Earthing tabs.
- 5. Specifications are for nominal input voltage, 25°C and max load unless otherwise stated.
- 6. Derate output power per chart below.
- 7. To enable output, power supply is shipped with J3 pin 4 and pin 6 shorted to enable main output.
- 8. Specifications subject to change without notice.
- 9. Warranty 2 years.

# MEDICAL 200 W AC/DC - Single Output

### **GENERAL SPECIFICATIONS:**

Hold I in Time	120 Vac	10 mSec
Hold Up Time	230 Vac	10 mSec
MTBF	>200 khrs	Bellcore TR-332
Switching Frequency	PFC converter variable 35 to 250 kHz, 90 kHz typical	Resonant converter : Variable 35 to 250 kHz, 90 kHz typical
Isolation Voltage	Min 4242 Vdc	Input to Output
Weight	325 g (0.72 lbs)	

### **ENVIRONMENTAL:**

Operating Temperature	-20 to 70 C	See derating charts below
Altitude	Operating 10,000 ft.	Non-operation 40,000 ft.
Conducted emissions:	EN55022, FCC part 15 Level B	
Storage Temperature	-40 to +70 C	
Humidity	95%	Non Condensing
Radiated Emissions	EN55022, FCC part 15 Level B	To be controlled in end system
Electromagnetic Susceptibility	EN61000-4	2, 3, 4, 5 Level 3
Harmonic Current	EN61000-3-2, Class D	

### **SIGNALS:**


Power Good Signal	TTL signal goes high after main output is in regulation band. Delay is 0.1 to 0.3 sec.
Power Fail Signal	TTL signal goes low 1 msec advance before output goes out of regulation due to mains failure
Remote ON / OFF	To turn-on power supply short J4 pin 3 to J4 pin 6
Remote Sense	Compensates for 200 mV cable drop


#### **SAFETY:**


EN / UL / CSA: 60601-1 3 <sup>rd</sup> edition	
Safety File Numbers	Pending




# MEDICAL 200 W AC/DC - Single Output









MECHANICAL OUTLINE DIMENSIONS ALL DIMENSIONS ARE IN INCHES [MM] GEN. TOLERANCE: +/-0.02 [+/-0.5]

# MEDICAL 200 W AC/DC - Single Output

#### **MECHANICAL:**

Input = J1	Ground	DC Output = J2	FAN= J3	
Pin 1: AC Neutral Pin 2: AC Line	Molex: 19705- 4301	Pin 1 = RTN Pin 4 = Vout Pin 2 = RTN Pin 5 = Vout Pin 3 = RTN Pin 6 = Vout	Pin 1 = + Remote Sense Pin 2 = Vfan (+12 V) Pin 3 = - Remote Sense Pin 4 = Inhibit Pin 8 = Power Good	
Mating Connector: Molex: 09-50- 3031 Pins: 08-50-0106	Mating Connector: Molex: 190030001	Mating Connector: VHR-4M, Pins: SVH-41T-P1.1	Mating Connector: Molex: 22-01-2087, Pins: 08-50-0113	

Copyright © 2010 Power-One Inc. All rights reserved. Words and logos that are identified as trademarks and/or service marks are, unless noted otherwise, the trademarks and service marks of Power-One Inc. in the U.S. and other countries. All other product or service names are the property of their respective holders. Power-One products are protected under numerous U.S. and foreign patents and pending applications, maskwork rights, and copyrights. Power-One reserves the right to make changes to any products and services at any time without notice. Power-One assumes no responsibility or liability arising out of the application or use of any information, product, or service described herein except as expressly agreed to in writing by Power-One Inc.

<sup>1.</sup> NUCLEAR AND MEDICAL APPLICATIONS - Power-One products are not designed, intended for use in, or authorized for use as critical components in life support systems, equipment used in hazardous environments, or nuclear control systems without the express written consent of the respective divisional president of Power-One, Inc. 2. TECHNICAL REVISIONS - The appearance of products, including safety agency certifications pictured on labels, may change depending on the date manufactured. Specifications are subject to change without notice.